

Processing Guide

The processing guidelines contained in this document were developed through in-house testing and field experience. However, they should be considered to be starting points that will require further adjustment. Read the following review of processes for applicability to your particular Printed Wiring Board (PWB) fabrication environment. Remember that the suggestions contained herein can not account for all possible board designs or processing environments. Additional adjustments by the fabricator will be necessary. Isola can and will assist with this process, but the fabricator, not Isola, is ultimately responsible for their process and the end results. **Fabricators should verify that PWBs made using these suggestions meet all applicable quality and performance requirements.**

Part 1: Prepreg Storage and Handling

Isola Group's prepreg bonding sheets for use in multilayer printed circuit board applications are manufactured to specifications that include physical and electrical properties and processing characteristics relative to the laminating application. Handling and storage factors have an important influence on the desired performance of the prepreg. Some parameters are affected by the environment in which prepreps are stored. They can also deteriorate over extended periods of storage. The prepreg received by the customer is a glass fabric that has been impregnated with a stated quantity of low volatile, partially polymerized resin. The resin is tack-free but somewhat brittle. Many lamination problems arise from resin loss off the fabric due to improper handling. The fabric used is based on the order and supplies the required thickness. In most cases the amount of resin carried by the fabric increases as the fabric thickness decreases.

Handling Suggestions

Handle all prepreg using clean gloves. Use sharp, precision equipment when cutting or paneling prepreg. Treat all prepreg as being very fragile. Use extreme care when handling very high resin content prepreg (glass fabrics 1080 and finer).

Storage Suggestions

Upon receipt, all prepreg should be immediately moved from the receiving area to a controlled environment. All prepreg should be used as soon as possible using a First-In-First-Out (FIFO) inventory management system. If not handled properly, IS400HR prepreg will absorb moisture, which will lead to depressed Tg's and cure and affect flow in the press. If extended storage is required, separate facilities should be reserved with appropriate environmental control. Prepreg should be stored at ? 23°C and below 50% humidity.

Prepreg packages should be allowed to equilibrate to layup room conditions before opening to prevent moisture condensation on the prepreg.

Stabilization

Stabilization time will depend on storage temperature. In cases where storage temperature is significantly below room temperature, keep prepreg in package or plastic wrapping during stabilization period to prevent moisture condensation. Once the original packaging is opened, the prepreg should be used immediately. Remaining prepreg should be resealed in the original packaging with fresh desiccant. Storage should be in the absence of catalytic environments such as high radiation levels or intense ultraviolet light.

Part 2: Innerlayer Preparation

Isola Group's IS400HR laminates are fully cured and ready for processing. It has been the experience of most fabricators that stress relief bake cycles are not effective in reducing any movement of high performance laminates such as IS400HR. Therefore, it is suggested that the movement of unbaked laminate be characterized and the appropriate artwork compensation factors are used.

Dimensional Stability

The net dimensional movement of laminate after the etch, oxide and lamination processes is typically shrinkage. This shrinkage is due to the relaxation of stresses that were induced when the laminate was pressed as well as shrinkage contribution from the resin system. Most of the movement will be observed in the grain direction of the laminate.

There are situations that have been known to alter the proportion of shrinkage in grain versus fill direction in some board shops. These include autoclave pressing and cross-plying laminate grain direction to that of prepreg. While both of these practices have their advantages, material movement must be uniquely characterized.

Table 1: Initial Artwork Compensation Factors

Base Thickness	Configuration	Direction	Comp (in/in)
? 0.005?	Signal/Signal	Warp (grain)	0.0007-0.0009
"	"	Fill	0.0001-0.0003
"	Signal/Ground	Warp (grain)	0.0005-0.0007
"	"	Fill	0.0001-0.0003
"	Ground/Ground	Warp (grain)	0.0002-0.0004
"	"	Fill	0.0000-0.0002
0.006-0.009?	Signal/Signal	Warp (grain)	0.0005-0.0007
"	"	Fill	0.0001-0.0003
"	Signal/Ground	Warp (grain)	0.0003-0.0005
"	"	Fill	0.0000-0.0002
"	Ground/Ground	Warp (grain)	0.0000-0.0002
"	"	Fill	0.0000-0.0002
0.010-0.014?	Signal/Signal	Warp (grain)	0.0002-0.0004
"	"	Fill	0.0000-0.0002
"	Signal/Ground	Warp (grain)	0.0001-0.0003
"	"	Fill	0.0000-0.0002
"	Ground/Ground	Warp (grain)	0.0000-0.0002
"	"	Fill	0.0000-0.0002

Table 1 (for reference) illustrates the suggested approach to characterizing laminate movement and provides approximate artwork compensation factors for IS400HR laminate when using a hydraulic press.

This table assumes that laminate and prepreg grain directions are oriented along the same dimension. Each shop must characterize material behavior given their particular lamination cycles, border designs and grain orientation of laminate to prepreg. It is also suggested that specific laminate constructions be specified and adhered to so that dimensional variations due to changes in construction are avoided.

Table 1 assumes that signal layers are either half or 1 ounce copper and ground layers are either 1 or 2 ounce copper.

Imaging and Etching

IS400HR laminates are imaged using standard aqueous dry films and are compatible with both cupric chloride and ammoniacal etchants.

Bond Enhancement

Both reduced oxides and oxide alternative chemistries have been used successfully in fabricating IS400HR multilayer boards to date. Users should make sure the oxide or oxide replacement coating exhibits a consistent and uniformly dark color.

If reduced oxides are used, consult the chemical supplier for post oxide baking considerations as excessive baking may lead to lower pink ring resistance. It is generally suggested that post-oxide baking be performed vertically, in racks. Suggest mild bake of oxide coated innerlayers (15-30 minutes @ 80-100°C).

For conveyORIZED oxide replacements, an efficient dryer at the end of a conveyORIZED oxide replacement line should remove all moisture from the innerlayer surface. **However, drying of layers for 30 minutes minimum @ 100°C or higher is considered a “best practice”, especially for boards to be subjected to “lead-free” processes. Drying in racks is preferred.**

If immersion tin adhesion treatments are used, the fabricator should test the coating to verify adequate bond strength develops with IS400HR prepregs.

Table 2: IS400HR General Lamination Parameters

Process	Recommendation
Vacuum Time	20 minutes (no pressure, product on risers)
Curing Temperature	180°C (355°F)
Curing Time	60 minutes (above 180°C (355°F) 75 minutes cure for >3 mm thickness)
Resin Flow Window	80-135°C (180-280°F) Maintain heat ramp in this temperature range
Heat Ramp	2.5-3.5°C/min (4.5-6.5°F/min)
Pressure	225-300 PSI 16-21 kg/cm ²
Pressure Application	-Single Stage: Apply pressure after vacuum dwell time. -Dual Stage: 3.5 kg/cm ² (50 PSI) after vacuum dwell time, switch to high pressure ? 80°C (176°F) product temperature
Pressure Drop	After 30 minutes at cure temperature, reduce pressure to 3.5 kg/cm ² (50 PSI) in hot press (optional).
Cool Down	Cool to 135-140°C (275-285°F) at 2.8°C/min (5.0°F/ min) with 3.5 kg/cm ² (50 PSI) pressure prior to removing or transferring the load.

Table 2 outlines general suggestions for lamination temperature and pressure based on press type used.

Part 3: Lamination

Standard Lamination

IS400HR prepreg materials achieve maximum fluidity at approximately -7°C (20°F) lower temperatures as compared to standard FR406 prepregs.

Therefore, it is recommended that lamination press cycles with a delay, kick over to a high pressure (kiss cycle) be adjusted accordingly due to the lower melt and maximum fluidity temperatures. Additionally, vacuum assist lamination processes are suggested. Non-vacuum lamination processes should be reviewed by Isola technical service engineers prior to production implementation.

Sequential Lamination

Use a 60 minute cure for sub-assemblies depending on thickness and a **60-70 minute cure for the final assembly.** This suggestion assumes a final

assembly thickness ? 0.125? (3.2 mm).

Removal of IS400HR flash should be performed by routing rather than shearing to minimize crazing along the panel edges.

Single-Stage and Dual-Stage Press Cycle Lamination

The suggested lamination parameters for the single-stage and dual-stage lamination cycles are shown in Table 2 and Table 3. The lamination cycle selected will be a function of board stack up, complexity and thickness as well as the lamination presses capability. **Thicker boards may require additional dwell time at curing temperature to achieve full cure.** See “Standard Lamination” previously discussed.

Choosing a dual stage or “kiss” cycle for IS400HR multilayer boards may improve results in some applications. Use these cycles to enhance the wetting of the glass along the extreme edges and corners of the panel or to minimize circuit image transfer (“telegraphing”) on foil constructions.

All cycles include a pressure reduction step in the lamination cycle, which facilitates stress relief of the package during the cure step. Further, all cycles assume vacuum is maintained throughout the heating cycle and all cycles presume that the book is cooled to a temperature well below the Tg of the material before the press is opened. All three conditions are considered to represent “best practice” conditions during lamination by Isola.

While use of both the pressure drop cycle and cooling well below Tg in the “hot” press are strongly suggested, these steps are considered to be “optional” and the PCB fabricator may have equipment or capacity limitations which prevent following these suggestions.

Part 4: Drill

General

The IS400HR material has high thermal performance and stability. Due to this high thermal performance, the material tends to form free standing chips during drilling, and is not likely to create drill smear. Due to the increased thermal decomposition properties of the resin system, the IS400HR drill debris remains as free particles and will not impact the drill flute relief volumes.

To assure effective removal of the resin debris during drilling, undercut drill geometries and high helix tools are suggested. On high layer count technologies and thicker overall board thicknesses, peck drilling parameters may be necessary. Suggested parameters are outlined below for typical multilayer designs.

Cutting Speed and Chipload

Relative to standard FR-4 parameters, use lower chiploads to drill IS400HR printed circuit boards. The parameters in **Table 3** provide a moderate initial starting range for typical board designs. Thick boards with heavy copper or special cladding such as invar will require more conservative drill parameters. Boards with numerous 2 oz. copper innerlayers or boards with coarse glass weave may require more conservative parameters. Peck drilling techniques are suggested for boards with thickness > 0.100? (2.5 mm).

Stack Height and Hit Count

Stack heights and hit counts will vary with construction and overall thickness of the boards being drilled. For thicker boards (above 75 mils or 1.91 mm overall) with high layer counts, drill one high.

Aluminum entry and lubricated backing help create good quality hole walls but are not essential in all applications. Do not exceed 1,000 hits for bits below 0.014? diameter and 1,500 hits for bits above 0.020?.

Table 3: Suggested Drilling Parameters For Initial IS400HR Setup

Drill Size		Spindle Speed	Surface Speed Per Minute		Infeed		Chipload		Retract	
mm	inch	RPM	SFPM	SMPM	Meter min.	Inch min.	mm rev	mil rev	Meter min.	Inch min.
0.25	0.0098	120,000	94	309	2.2	85	0.018	0.71	15	600
0.30	0.0118	115,000	106	356	2.5	100	0.022	0.87	20	800
0.35	0.0138	110,000	121	397	2.7	105	0.024	0.95	25	1000

0.40	0.0157	105,000	132	433	2.7	107	0.026	1.02	25	1000
0.50	0.0197	90,000	141	464	2.5	99	0.028	1.10	25	1000
0.65	0.0256	80,000	163	536	2.9	115	0.037	1.44	25	1000
0.75	0.0295	75,000	177	580	3.4	135	0.046	1.80	25	1000
1.00	0.0394	62,000	195	639	3.5	136	0.056	2.19	25	1000
1.25	0.0492	50,000	196	644	3.0	120	0.061	2.40	25	1000
1.50	0.0591	42,000	198	649	3.0	118	0.071	2.81	25	1000
2.00	0.0787	31,000	195	639	2.2	87	0.071	2.81	25	1000

Part 5: Hole Wall Preparation

General

Good desmear and electroless copper deposition performance are more easily achieved when the drilled hole quality is good. The generation of smooth, debris free hole walls is influenced by the degree of resin cure, drilling conditions and board design considerations. The elimination of 7628 or similar heavy glasses (whenever possible), coupled with properly adjusted drill parameters on fully cured boards has been shown to improve overall drilled hole quality. This helps reduce smear generation, which improves desmear performance and can ultimately help to reduce copper wicking.

Factors which influence chemical desmear rates, and therefore the suggestions in this document, include: resin type, chemistry type, bath dwell times, bath temperatures, chemical concentrations in each bath and the amount of solution transfer through the holes.

Factors which influence the amount of solution transfer through the holes include: hole size, panel thickness, work bar stroke length, panel separation in the rack and the use of solution agitation, rack vibration and rack “bumping” to remove air bubbles from the holes.

Chemical Desmear

Dwell times and temperatures typically used for most high performance materials should be satisfactory. Consult the chemical supplier for suggested conditions.

Plasma Desmear

IS400HR generally does not require plasma etching. If available, plasma can be used with or without a single permanganate pass (to be determined by each fabricator). Plasma has been determined to readily remove IS400HR resin. Plasma processing tends to improve overall hole quality, particularly in thick and/or high aspect ratio boards. Standard plasma gas mixtures and cycles are satisfactory.

3-Point Etchback

True 3-point “Etchback” exposes the innerlayer “post” on all three sides for subsequent plating processes. This will require a more robust approach compared to simple desmear, which is designed only to remove resin smear from the vertical surface of the innerlayer interconnect “posts”.

Keep in mind that processing through permanganate chemistry alone is not suggested to attain a full 3-point etchback for IS400HR.

Plasma will readily etch back IS400HR resin. Standard plasma gas mixtures and process cycles designed for conventional FR-4 epoxy are satisfactory and are suggested for use as initial starting parameters for etchback of IS400HR. The practice of following the plasma process with a chemical process is suggested rather than plasma alone to increase hole wall texture and remove plasma ash residues. Consult the chemical supplier for suggested conditions.

If plasma is not available, chemical etchback for 3-point connections must be done with extreme care on IS400HR to minimize copper wicking.

Secondary Drilling

As common with most high Tg epoxy materials with increased modulus properties, the use of entry and backer material may be necessary during the secondary drilling of larger hole sizes to avoid crazing/fracturing at the hole perimeter. Additionally, sharper plunge point angle geometries may be necessary to avoid crazing around secondary drilled hole perimeters.

Routing and Scoring

Due to the greater modulus properties of the IS400HR materials, modifications of the final PWB rout fabrication process may be necessary. **Table 4** lists initial starting parameters using chip breaker or diamond cut tool designs. **Note that parameters listed may require further adjustment.**

Table 4: Suggested Routing Parameters for Initial IS400HR Setup

Tool Diameter		Spindle Speed	Spindle Travel Speed	
Inch	mm		Inch min.	Meter min.
0.0620	1.5748	45,000	20	0.508
0.0930	2.3622	35,000	40	1.016
0.1250	3.1750	25,000	50	1.270

For PWB designs requiring scored geometries, the testing of various Tg's and resin content materials has determined that adjustments to the process will be necessary. As the modulus strength of materials increases, the maximum resultant web thickness (dependent on the scored edge depth) must be decreased to avoid excessive fracturing upon breaking away the scored materials.

Individual board designs/stack-ups may require adjustment of score depth geometries. **Thinner web thicknesses are typically required.** This is influenced by layer count, glass types and retained copper in the design.

The customer should contact the scoring equipment and/or bit supplier for application specific suggestions for use with IS400HR materials.

Your Isola Technical Account Manager may also be able to provide some initial suggestions, but these should be reviewed with the scoring equipment supplier and validated through testing by the individual PWB fabricator.

Part 6: Packaging and Storage

IS400HR finished boards have low moisture sensitivity and good shelf life. However, Isola recommends using best practices in storage and packaging, as noted below, to reduce risk during lead-free assembly.

IS400HR boards should be dry prior to packaging to ensure the most robust lead-free performance. For some complex, high reliability designs, baking prior to solder mask application can be implemented to ensure maximum floor life in assembly processing. Printed boards made for high temperature assembly from IS400HR, which require a long shelf life, the best protection is provided using a Moisture Barrier Bag (MBB) with a Humidity Indicator Card (HIC) and adequate drying desiccant inside the MBB to prevent moisture absorption during shipment and long-term storage.

Upon opening the MBB, the boards should be processed within 168 hours when maximum shop floor conditions are at < 30°C (85°F)/60% RH. MBB bags that are opened for inspection should be resealed immediately to protect the boards from moisture uptake.

Part 7: Health and Safety

Always handle laminate with care. Laminate edges are typically sharp and can cause cuts and scratches if not handled properly. Handling and machining of prepreg and laminate can create dust (see IS400HR Material Safety Data Sheet).

Appropriate ventilation is necessary in machining/punching areas. The use of protective masks is suggested to avoid inhaling dust. Gloves, aprons and/or safety glasses are suggested if individuals have frequent or prolonged skin or eye contact with dust.

Isola Group does not use polybromidebiphenyls or polybromidebiphenyloxides as flame retardants in any product. Safety Data Sheets are available upon request.

Part 8: Ordering Information

Contact your local sales representative or visit: www.isola-group.com for further information.

Or contact us at: info@isola-group.com

Isola Group North America

6565 West Frye Road

Chandler, AZ 85226
Phone: 480-893-6527
Fax: 480-893-1409

Isola Asia Pacific (Hong Kong) Ltd.

12/F, Kin Sang Commercial Centre,
49 King Yip Street, Kwun Tong,
Kowloon, Hong Kong
Phone: 852-2418-1318
Fax: 852-2418-1533

Isola GmbH

Isola Strasse 2
D-52348 Düren, Germany
Phone: 49-2421-8080
Fax: 49-2421-808164

The data contained in this document, while believed to be accurate and based on both field testing and analytical methods considered to be reliable, is for information purposes only. Any sales of these products will be governed by the terms and conditions of the agreement under which they are sold.

NOTES

The data contained in this document, while believed to be accurate and based on both field testing and analytical methods considered to be reliable, is for information purposes only. Any sales of these products will be governed by the terms and conditions of the agreement under which they are sold.

Isola, the Isola logo, Astra, Chronon, GETEK, I-Fill, IsoDesign, IsoStack, I-Speed, I-Tera, Polyclad, Stratus, TerraGreen, and The Base for Innovation are registered trademarks or trademarks of ISOLA USA Corp. in the United States and in other countries. Copyright © 2021 Isola Group. All rights reserved.